

Safety Precautions:

This safety note describes how to make your child enjoy this book happily and safely.

Products, please be patient to read the following safety precautions.

1. When charging, you must do it from an adult. Do not let the child charge himself.
- 2, must drive this car under the supervision of adults
3. This product must be assembled by adult adults before being assembled or used.
4. It is strictly forbidden to drive in dangerous places such as the swimming pool on the public street.
- 5, the car can not overload the maximum load capacity of 30 kg
6. This product is only suitable for children aged 37 months and above. Do not use children 3 years old and younger.
7. Note that some parts will be damaged due to improper driving.
8. It is strictly forbidden to change suddenly during driving. The forward switch function should change the switch function during stationary.
9. After the car is dirty, it can only be scrubbed with a clean cloth. Do not rinse with water to avoid damage to the components.
- 10, the charger is not a toy, please collect after charging
- 11, the product is a plastic product, please stay away from fire.
12. When the product is in use, the motor will generate sparks when it starts. Therefore, it is strictly prohibited to burn at the gas station. Use in areas such as explosive danger
13. Please pay special attention to let the child touch the wheel or the position near the wheel to avoid pinching and crushing. Do not let other children approach the car while in use.
14. The car is suitable for driving on a flat ground. Please try to avoid driving in silt or uneven terrain.
15. Do not play the children's packaging on the removed clothes to avoid accidental danger to children.
- 16, the product is for the child to make the guardian responsible for the month before the month to explain the contents of the instructions to guide the child correctly

Operational use

17. The seat belt attached to the car is only a toy that adds safety awareness to children.

Safety function of human vehicles

- 18, please guide children how to relax the accelerator pedal How to deal with the pedals and the car when the obstacles and how Stop the car.
19. Insert the battery correctly, pay attention to the positive and negative poles.
20. The battery can be recharged but not heated and thrown into the fire to avoid short circuit.
- 21, non-storage battery can not charge the battery can only be charged under the supervision of adults
22. When the battery power is insufficient, the remote control distance will become shorter. Please replace the battery with new one.
23. If the battery is not used for a long time, please remove the battery to avoid leakage. If the battery is dead, it should be taken out of the vehicle body.
24. The power terminals must not be short-circuited. Please check the product and the charger used regularly to see if the wires, plugs, casings and other components are Damaged, should be discontinued when damage is found, until the repair is in good condition.

Children's electric four-wheeler


Installation instructions



Parts


			
front wheels	mirrors	Rear wheel cover	rear wheel
			
Bodywork	remote control	charger	Front wheel

installation steps



Install the front wheel: first put the Shim into the front axle, then put the front wheel and Shim into the front axle clamp tightly, finally fasten the wheel Shim. The Front axle clamp is clamped for times, and the wheel sheet is fastened finally

installation steps



First remove the seat plate, connect the power cord, and press the seat plate to the card slot and press firmly



Install the reflector:
install the reflector as shown
in figure.