

Description

Name	DK-P911
Battery	24V7AH / 24V10AH / 24V14AH
Motor	24V4000 RPM of WW4853# driving motor (Mute motors)
Max load weight	60 KG
Size	1480*900*560mm
Speed	5-12 KM/H
Charging time	8-14 hours
Remote control battery	AAA battery 1.5V*2 (not including)
Applicable age	6+ years
Charger specification	Input: 220V / 110V 24V Output: DC28.8V800mA or DC24V1000mA

Charging the Drive Battery:



IMPORTANT! Before using the unit for the first time the battery needs to be charged for at least **8 to 14** hours - no more than **20** hours. Once battery is depleted, recharge for **8 to 14** hours - no more than **20** hours.

IMPORTANT!

Check the drive battery and charger (supply cord, connector) for wear and damage before charging. Do not charge the battery if damage has occurred. Only replace with the same type and voltage rechargeable battery and charger supplied by the manufacturer.

- Only use the rechargeable battery (or equivalent replacement) and charger supplied with your vehicle.
- Always turn power off and charge battery after riding.
- The drive battery should be charged when depleted, or if not used regularly, once a month. Failure to charge the battery as directed will cause permanent damage to the battery and will void the warranty.

STEPS:

1. Locate Charging Port.
2. Plug Charger plug into unit Charging Port.
3. Plug Charger into Wall outlet.
4. When battery is fully charged, unplug charger from the wall outlet and disconnect from charger port.

NOTE: The charger may feel warm during the charging. If excessively hot, unplug and replace.

NOTE: This product has charging protection: When charging, all functions are turned OFF.

Installation And Operation Manual



Model: DK-P911

Applicable age: 6+ years

Maximum weight: 60 KG

Execution Standard:

GB6675&GB19865 EN71&EN62115 ASTM-F963



© 2025 Porsche AG. Porsche Crest, Porsche Logotype, 911 and GT3 are trademarks of Porsche AG used under license.

Pinghu Dake Baby Carrier Co.,Ltd

Address: No.88,Qinsha section,Pinglang Road,Xincang Town,
Pinghu City, Jiaxing City,Zhejiang Province ,China

Website: www.daketoy.com

Warning: This is a Child's Toy and NOT intended for Off-Road Use.

1. Separe parts list

Car body 1 PC	Window shield 1 PC	Rearview mirror 1 Pair
Steering wheel 1 PC	Driver's seat 1 PC	Passenger's seat 1PC
Rear cover 1 PC	Black decoration of rear cover 1 PC	
Rear tail wing 1 PC	Support parts for rear tail wing 1 Pair	
Wheel cover 4 PCS	Decoration of wheels 4 PCS	Wheel cap 4 PCS
Front wheels 2 PCS	Rear wheels 2 PCS	Manual 1 PC
Remote control 1 PC	Charger 1 PC	Spanner 2 PCS
MP3 line 1 PC (not including with MP4 version)		
Decoration on dashboard 1 PC (not including with the MP4 version)		
4.7 inch MP4 player 1 PC (Optional 1)		
7 inch Removable MP4 player 1 PC (Optional 2)		
Screw bag: 1 PC Including: M12 gasket - 5 PCS (1 PC for spare part); M4*12mm screw - 20 PCS (2 PCS for spare parts); M4*10mm screw - 22 PCS (2 PCS for spare parts); M10 nut - 1 PC (Spare part); M16 gasket - 2 PCS;		

Instructions

WARNING!

For safety reasons,

- *please use this vehicle under adult guidance and supervision.
 - *do not use this product on main roads, slopes, highways or other dangerous places.
 - *children must wear shoes and protective gears when operating the vehicle.
 - *children should be seated with the seat belt fasten when driving.
 - *only load a maximum of 60Kg on the vehicle.
 - *only children aged 6+ years should be allowed on this vehicle.
 - *use this toy strictly according to safety manual.
 - *please check the tires, breaks, steering wheels, seats and seat belts before operating vehicle.
 - *this toy vehicle should be used with caution and requires skill to avoid fall or collision with third parties.
 - *Non-rechargeable batteries are no to be recharged;
 - *The supply terminals are not to be short-circuited.
 - *Rechargeable batteries are to be removed from the toy before being charged;
 - *The toy should be regularly examined for damage to the cord,plug,anclosure and other parts,and in the event of such damage,they must not be used until the damage has been repaired.
 - Only use the battery specified by the manufacturer
 - Only use the charger specified by the manufacturer.
- Pictures are for reference only,please adhere to the original Products as standard

The product must be assembled by Adults.

Warning! Not suitable for children under 6 years.

Long cord. Strangulation hazzard.

Pictures are for reference only, please adhere to the original products as standard.

WARNING:

The car contains battery that are non-replaceable.

The instruction manual must be retained since it contains important information.

WARNING:

For the purposes of recharging the battery, only use the detachable supply unit provided with this toy,DC adaptor.

WARNING:


The remote control is not a toy. It is for adult use only, and should not be used by a child. A close adult supervision is always required. Reception range may change significantly with weather, battery, and other environmetnal conditions.

WARNING:

RISK OF FIRE.DO not bypass. Replace only with HY2005M-ADP-HL-24V Max 40A.

Installation steps

2. Names of spare parts



Installation steps


3. Installation steps

Step 1: Install front wheels

A: Install decoration of wheels onto the front wheels.

B: Install spare parts onto front axle following the sequences:

M16 gasket - Front wheel - M12 gasket - M10 nut - Wheel cover - 5 PCS of M4*10mm - Wheel cap.




Step 2: Install rear wheels

A: Install decoration of wheels onto the rear wheels.

B: Install spare parts onto rear axle following the sequences:

Rear wheels - M12 gasket - M10 nut - Wheel cover - 5 PCS of M4*10mm - Wheel cap.



Instructions

01. While driving , adult supervision is required all the time
02. Always wear a helmet when driving
03. Please don't drive near road or on the footpath.
04. It is not recommended to drive the vehicle on wet surface or on slope greater than 15-degree.
05. It is recommended to drive this vehicle on smooth surface only.
06. Please don't drive this vehicle outdoors when it is raining.
07. Make sure that the vehicle stop completely before changing direction from forward to reverse
08. Please don't allow children to operate the charger or play with the battery
09. Clean the vehicle with a dry cloth only.
10. Please follow the correct weight and age limits allowed to drive this vehicle.
11. It is prohibited to change the circuit or add other electric parts.
12. Adults must teach their children about safe driving procedures.
13. Please turn the power off when not in use.
14. Check the seat to ensure it has been fitted and secured with a bolt before driving.
15. Inspect all wires and connection of the vehicle periodically.
16. Charging the battery should only be done by adults.
17. Charging plug is located underneath the seat.
18. In order to avoid accidents, please ensure the vehicle is safe before driving.
19. Please don't let children touch the wheels or be near them when the car is moving.
20. Please mind fingers when opening and closing doors.

WARNING:

To reduce the risk of injury, adult supervision is required. Never use in roadways, near motor vehicles, on or near steep inclines or steps, swimming pools or other bodies of water; always wear shoes, and never allow more than 2 riders.

Warning: This toy cannot be used in the sands.

Instructions

Troubleshooting

Problem: The vehicle cannot be driven.

Cause of the problem: the battery is insufficient

Please charge in time after each use, and charge at least once a month.


It is recommended to charge for 8-14 hours, not more than 20 hours.

Problem: The car does not move.

Answer: The battery is low, please charge for 8-14 hours

but not exceeding 20 hours.

Charge at least once a month to keep the battery cells active.



To avoid short fuse or power cut off:

1. Do not overload the product. Max load is 60 Kg.
2. Do not drag any item behind this product.
3. Do not allow water or any liquid into electric parts.
4. Do not change wire system without a professional.

TROUBLESHOOTING

Problem: The car only runs for a short time.

Answer 1: The battery is low, please charge for 8-14 hours

but not exceeding 20 hours.

Charge at least once a month to keep the battery cells active.

Answer 2: The battery may need to be replaced depending on its charging history and age.

Problem: The sound does not work.

Please ensure the volume is turned up and the MP3 line is not connected. Sounds from steering wheel will not work when MP3 is plugged in.

Problem: Charger overheating.

It is normal for battery and charger to be slightly warm during charging.

If the charger feel excessively hot, please check for a current overload or battery short circuit.

Installation steps


Step 3: Install steering wheel

A: Remove 1 PC of M5*35 screw and 1 PC of M5 nut from the steering shaft hole.

B: Connect the steering wheel properly with the lines on dashboard.

C: Insert steering wheel into dashboard, make sure align the steering wheel with the steering shaft hole.


D: Use 1 PC of M5*35 screw and 1 PC of M5 nut to fix.



Step 4: Install decoration on dashboard or 2 kinds of MP4 players

A: Insert the decoration on dashboard or the 4.7 inch MP4 (optional 1) into the dashboard slot.


B: Insert the 7 inch Removable MP4 (optional 2) from top to bottom into fixing plate.



Installation steps


Step 5: Install window shield

Stuck the window shield into the car according to the figure below.




Step 6: Install rearview mirrors

Stuck the rearview mirrors(left and right) into the sides of the car according to the figure below.




Instructions

4. Introduction for switches



5. Introduction for MP3



Instructions


Step 13: Install the assembled rear tail wing

Stuck the assembled rear tail wing into the car according to the figure below.



Diagram of the 2 hidden tugboats

When the car is powered off, it can be easily pulled by adults. Adults need to pull out the 2 hidden tugboat under the car and lift the front of the car.




Installation steps

Step 7: Connect the power


Connect power cables with red plug in part.

* Diagram of power connection and battery compartment as below:



Step 8: Install rear cover


Insert the rear cover into the slot, and secure it with 4 pcs of M4*12mm screws.



Installation steps


Step 9: Install black decoration of rear cover

Insert the black decoration of rear cover into the slot, and secure it with 10 pcs of M4*12mm screws.



Step 10: Install passenger's seat

- A: Put the passenger's seat into the car.
- B: Fix the seat by locking the lock catch.




Installation steps

Step 11: Install driver's seat

A: Pull the driver's seat with the sliding handle under the driver's seat as shown in the figure;

B: Slide the driver's seat into the base slot, ensure that the driver's seat is properly secured to the base, then pull the driver's seat to the end to place it in the car body slot.

* Driver's seat slides forward and backward with 3 gears.



Step 12: Install support parts for rear tail wing

Insert the support parts for rear tail wing into the both sides of rear tail wing, and secure it with 4 pcs of M4*12mm screws.

