

CHILDREN 'S BATTERY OPERATED RIDE-ON CAR INSTRUCTION MANUAL

Remote control and manual operate

With horn,music and early education function on steering wheel

With usb and sd connection

Remote control operate forward;backward;turn left and right

Manual-gear control to movement forward and backward

With swing function



Assembly must be operated by adult only

Picture just for reference,please refer to the actual products


In order to explain well the operation and the construction, we used some pictures, if the pictures are different with the actual products, please refer to the actual products.
In order to improve our quality different, we may change some parts without any further notice.

Please read this manual before use, it tells you how to operate the car and how to assemble the car, and avoid wrong operation cause the damage to the car or the hurt to your kids.
Keep this manual well


Specification ---

Description	Specfication
Battery and fuse	Dual-drive(12V7AH/ 12V4.5AH),resettable fuse:15A/10A
Motor	Dual-drive 12V
Suitable for:	37-95 months
Load capacity:	25kgs
Product size:	108X64X46cm
Speed:	3-4km/h
Charing time:	8-12hours
Use time:	1-2hours
Charger:	Input:220V Output:DC12V1000MA or DC12V500MA

Parts list _____




Number	Description	Quantity	Number	Description	Quantity
1	Car body	1	5	Front Wheel	2
2	Seat	1	6	Rear Wheel	2
3	Steering wheel	1	7	Drive motor	2
4	Car window	1	8	Reversing mirror	2



1. Install the front wheels:

- The front wheel in front axle, before loading into a $\Phi 10$ gaskets, hear the "click" sound to put in place.
- The other front wheel is also installed.



2. Install rear wheel and drive motor:

- Drive the motor to the rear axle from the left side of the body (to ensure that the line on the drive motor goes through the line hole in the body to the battery compartment). If the product has been installed, this step can be ignored.
- Then put the back wheel with the plum blossom into the back axle until you hear the click sound to put in place.
- The right rear wheel is also installed.



3. Installation of rearview mirror:


- Insert the rearview mirror into the hole in the car body and press down until you hear the "click" sound to indicate that the installation is in place.
- Use the same method to install the rearview mirror on the other side.



4. Install the windshield:

- Insert the card into the corresponding slot in the card slot and press down until you hear the "click" sound, indicating that the buckle is installed in place and the wind shield is completed.

Assembling and operation





5.Assemble the steering wheel(refer to picture 5)

A:Insert the steering shaft into the hole on steering wheel, make sure the hole on steering shaft match with the hole on steering wheel,then insert the M5 bolt into the hole, tighten the bolt with a nut.



6.Assemble the seat(refer to picture 6)


As shown in the figure, the seat latch should be rotated to unlocking position, and then please align the fixing pin at the seat's fixing hole, press it down and rotate the latch to locking position.



Operation

A:Resettable fuse:(refer to picture 1):when the currenacy achieves 15A/10A, the power is off and 5-10 seconds later it is normal.

How to operate




A: After the kid seat on the car, turn on the power, set the swing-drive switch to the drive position, set the forward-backward switch to the forward position, pedal the pedal, the car goes forward, release the pedal, the car stops, set the forward-backward switch to backward position, pedal the pedal, the car goes backward, release the pedal, the car stops, set the forward-backward switch to stop position, the car can't move, steering wheel controls the direction (left or right), set the swing-drive switch to swing, the car can't move, starts swing (remote control priority, when you use the remote control, the remote control controls the car (forward; backward; left or right), and no any sound when you press the music button on steering wheel.

B: Turn on the light switch, front light and rear light are lighting, turn on the bubbles switch, there are bubbles come out from the head of the car.

C: Charging the battery: when the battery capacity is low, please recharge the battery immediately, charging socket is under the dashboard.

Attention: when charging, the power is cut off. Charging must be operated by adult only.



Assemble the battery on the remote controller: open the cover of the battery box, add two pcs of AA 1.5V battery, please pay attention to the polarity, close the cover of the battery box, tighten the screw to fix the cover (change battery please refer).

Troubleshooting

Type	Causes	Solutions
The car doesn't move.	1. The battery voltage is too low; 2. Electrical protection; 3. The switch isn't operated properly; 4. The battery connectors drop off; 5. Abnormal battery; 6. Electrical damage; 7. Motor failure;	Charge the batteries fully; Stop for a few minutes and restart ; Reinsert; Replace with a new battery; Contact maintenance personal for further repair ; Contact maintenance personal for further repair ;
The battery can't be charged;	1. The battery connectors drop off; 2. The battery charger isn't powered on ; 3. The charger is damaged;	Plug in again; Plug in again; replace the charger;
Short working duration;	1. The battery runs off; 2. The battery is out of service life;	Fully charge the battery; Replace the battery;
Slight noise and heat during charging process;	1. Normal chemical reactions	Normal;
Slow running speed;	1. The battery is out of service life 2. The battery runs off 3. Overload 4. Uneven pavement	Replace the battery; Fully charge the battery again; Reduce weight to 35kg or less; Operate on a flat ground;
Gearbox noise;	Gear damage	Contact maintenance personal for further repair
Jitter during moving process;	1. Poor contact of motor cable. 2. Short-circuited motor.	Reconnect; Contact maintenance personal for further repair;
The car runs without voice;	1. Steering wheel connector is not plugged properly	Reconnect in accordance with the Manual;
The car can't stop;	1. Electrical damage	Contact maintenance personal for further repair;



WARNING

- For safe driving, please kindly pay attentions to the following warning matters:
- The product must be assembled and adjusted by adult, please keep children away from moving parts.
- The product doesn't apply to 36-month younger children due to internal small parts!
- During driving, a child must be fixed by seat belt properly. Do not close to any fire!
- Any child must be supervised by adult while using the product and such the adult caregiver should not leave during driving process.
- Do not allow your children to stand or play on the food pedal or in the electric car.
- The battery must be charged only by adult. Please charge the product before using!
- To avoid any harm to children, please keep plastic bags and other packaging materials away from children! Such the materials may cause suffocation!
- It is prohibited to use any parts from other manufacturers.
- The charger should not be played as a toy.
- The vehicle maximum load weight is 25 KG, and please do not use on overload.
- The product applies to children at **37-95** months;
- The toy should not be connected to excessive powers (more than the quantity specified herein), and it should not be operated during charging process.
- must with the protection device, can't use as traffic tools.
- this toy without braking device.

Instructions for **replaceable** batteries

- All batteries should be inserted with the correct polarity.
- Non-rechargeable battery should not be charged, please remove any running-off battery from the toy.
- Do not use old and new batteries together, or mix different types of batteries.
- Power terminals should not be short-circuited
- Any rechargeable battery must only be charged under adult's supervision.
Rechargeable batteries should be removed from the toy before charging.

Precautions for charging

- Before the initial using, the electric car batteries must be charged for 18 hours, thus to avoid permanent damage to the battery, otherwise, they will not be repaired.
- Insert the charger DC plug into the charging jack, and then plug the charger in power socket.
- After the product is operated each hour, it should be promptly charged, the normal charging time is 8-12 hours, and each charging time should not exceed 20 hours.
- In the charging process, it is a normal phenomenon the battery or charger becomes hot (less than 60 centigrade):
- Connect; when any water exists in the car, it is prohibited to charge, or it may cause short circuit.
- Only the original charger and battery with electric car must be charged or used to avoid any damage to the charger, battery, or short circuit.
- When the electric car is standby for a long time, it should be charged at least once a month.

Precautions for operations

- Before using, please check if various components are mounted properly and connected solidly.
- Do not operate in any streets, roads, slopes, ditches and other hazardous environment.
- Please do not operate on any smooth ground, such as marble and tiles.
- Do not switch between forward and backward during the moving process of electric car; do not allow your child to stand on the seat.
- Please do not modify the car's circuit or mount any additional eclectic device. Remote controller, and electric car should not be exposed to the rain or used in the water, Do not pour water or other liquids in the car or soak in water in other improper operating manner; please keep away from the fire source, in order to avoid circuit damage.
- When any obstacle appears, remove your child from the electric car, until the car goes cross the obstacle.
- Do not operate the product indoors to avoid furniture damage and children injury.
- When the remote controller battery is lack of power, the vehicle will be remotely controlled to move forward only, but not rightward / leftward, and the remote control distance becomes short, and the car is jittered, etc., please immediately replace the battery! When the acousto-optic battery is lack of power, the sound and light functions will be disenabled, but other functions are still normal.
- Replace the acousto-optic batteries immediately. The product should be only ridded by one person, and can't be overloaded; the maximum load is 25 KG. after using, please turn off the power switch; if it is to be standby for a long-time, the battery connector should be unplugged.
- Notes: The product images, features, and content are used only for reference, and the product in kind shall prevail.

Maintenances

- To prevent your baby from accidental injury, please inspect and maintain the car regularly.
- Please check if the attached components are complete, and please don't hesitate to contact us ASAP if find loss of quantity.
- Regularly check existence of any loose screws and damaged parts.
- Each component should be checked before installation or use,
- As for disassembly, please operate carefully in accordance with the manual, thus to avoid unnecessary damage.
- Please regularly check if the product and the charger are in good conditions, if any wires, plugs, and housings are damaged; any damaged should be replaced and repaired to intact.
- The product should be periodically cleaned, and please do not clean it with water thus to avoid any damage to electric elements; the product should be cleaned with a dry cloth.

