

GB:


IMPORTANT!
READ CAREFULLY AND KEEP FOR FUTURE REFERENCE

Warning:
Only for domestic use. Never leave your child unattended.

- DO NOT place this product near a window , as it can be used as a step by the child and cause the child to fall out of the window;
- Be aware of the risk of open fires and other sources of strong heat in the vicinity of the product;
- DO NOT place this product near a window where cords from blinds or curtains may strangle a child.


- a) please regularly check the product to avoid overturning of toys or other damage.
- b) to check all nuts and bolts for tightness and tighten when required.
- c) to check all coverings for bolts and sharp edges and replace when required.
- d) to check swing seats and other means of attachments for evidence of deterioration.
- e) to replace defective parts in accordance with the manufacturer's instructions.
- f) if the tables and chairs are damaged or parts are missing, please use the accessories provided by the original manufacturer for installation.
- g) when the tables and chairs are dirty, gently wipe the surface with a wet rag

Crown Step Stool Instruction



**PLEASE READ THIS MANUAL CAREFULLY
BEFORE USING THE PRODUCT AND KEEP IT FOR THE FUTURE USE**

Parts List



How to Install

