

Please read the manual before using the product. The manual and carton contain important information, please keep them properly for later references. If failure to following the instruction in the manual, it might be dangerous for your child.

In order to improve the product and quality, we may change the parts of structure, appearance, packing method, assembly method and function of the product without any notice. When there is any difference between the manual and the product, please subject to the actual product. We are sorry for any inconvenience.



The assembly manual of
battery operated car

Model: SX2118

Executive standard:

EN71-1

EN71-2

EN71-3




EN62115



WARNING:

Products should be assembled by an adult. Protective equipment should be worn. Not to be used in traffic. Not suitable for children under 3 years. Choking hazard- small parts. In unassembled state, contains potentially hazardous small parts. Please keep out of the reach of small children. Pay attention to the potential hazards of using the toy in areas other than private grounds.

PARTS LIST

PARTS NAME	PICTURE	QTY	PARTS NAME	PICTURE	QTY
Car body		1PC	Windshield		1PC
Steering wheel		1PC	Seat		1PC
Mirror		2PCS	Seat spare parts		1PC
Rear wheel		2PCS	Front wheel		2PCS
Driving motor		2PCS	Wheel cover		4PCS
Push bar (optional)		1PC	Rear axle		1PC
Adult's step wheel (optional)		1PC	Adult's step spare parts (optional)		2PCS
MP3 / MP4 player(optional)		1PC	Adult's step wheel axle / bushing		1PC
Charger		1PC	Hardware package		1PC
Remote control		1PC	Manual		1PC

WARNING:

This product is not the vehicle for transportation, it should be used under adult guidance. Parents should ensure that children have taken the safety measures before use.

The toy should be used with caution since skill is required to avoid falls or collisions causing injury to the user or third parties.


PRODUCT SPECIFICATIONS

Battery	12V7AH 12V7AH*2 12V14AH 12V14AH*2 12V10AH 12V10AH*2 12V12AH 12V12AH*2
Main material	PP
Suitable age	37-95 Months
Weight limit	30KG (without adult's step) ; 80KG (with adult's step)
Product size	without push bar: 124x74x55cm
	with push car: 174x74x108cm
Speed	3-5KM/H
Runtime	1-2 hours after charging for 8-12 hours, based on ride on conditions
Charger	Input AC 110-220V Output DC 12V-1000mA Input AC 110-220V Output DC 24V-1000mA
Fuse	Auto-reset fuse

Handle and caster wheels function (optional)


Pull out the handle and caster wheels out if needed, so you can carry the car easily. When not needed, push them back to save space.

Openable bonnet, easy maintenance



Adjustable Seat Function


Pull out the handle under the seat, the seat can be adjusted to front and back.



Push bar and adult's step function (optional)

When you hold the handbrake, the wheel is separated from the motor, so the adult can stand on the ground and push the car easily; When you release the handbrake, the wheel is coupling with the motor, the car can drive normally. The push bar can control the direction.

The adult's step is hung at the rear of the car, it has man-carrying function and can swing left and right . When no needed, pull the step outward , rotate and fix it by 90 degrees to save the space.



Assembly instruction


Car assembling should be done by the adults.

Take care of small parts. To avoid choking hazard, keep children away while assembling. Children under 36 months are prohibited to use.

Please count all the parts carefully before assembling and dispose the plastic bag properly. To avoid choking hazard, children are not allowed to play with the bag.


1.Windshield assembly

Align the windshield with the corresponding openings on car body, insert and push it into place, fix the screws from the bottom of car body.




2.Battery connection

Battery is under the engine cover. Before first use, open the engine cover, insert the fuse to connect the power.




3.Front wheel assembly :

Turn over the car body, keep the car upside down, use the prepared sleeve tool to remove the nut and washer, then attach the front wheel to the front axle, insert washer and fix the nut with sleeve tool. Assemble the wheel cover.




Drift front wheel assembly method:

Turn over the car body, keep the car upside down, use the prepared sleeve tool to remove the nut and 10mm washer ,no need to remove the 12mm washer, then attach the front wheel to the front axle, insert the 10mm washer and fix the nut with sleeve tool. Assemble the wheel cover.




Attention: After assembling one wheel, please assemble the other wheel in same method.

4. Rear wheel assembly (push bar specification): Insert the rear wheel, a washer of 8mm inner diameter to the rear axle, fix them with a cotter pin. Assemble the wheel cover.




Rear wheel assembly (other specification): Remove the nut and washer on rear axle, insert the rear wheel, a washer of 10mm inner diameter to the rear axle, fix with nut with the sleeve tool. Assemble the wheel cover. Assemble the other wheel in same method.




5. Steering wheel assembly

Match two connectors of the wires from steering wheel and steering column, hold the steering axle from the bottom of car body, align the holes on steering wheel and steering axle, insert the screw and fix the nut.




6. Seat assembly

Fix the seat tube head to the seat with 4*12 big flat head screws, then attach the seat base to the seat tube, push the seat base to the end of the tube, fix 4*12 big flat head screws. Install the assembled seat with the car body, fix with 4*16 big flat head screws.




7. Mirror assembly

Align the mirror with the corresponding opening on the car body, insert and push it into place.




8: U-shape iron part assembly (optional)

Insert U-shape iron part to the corresponding position at the rear of the car, there are two screw holes on the car body, fix the U-shape iron part with 4*40 flat head screws from these holes.(Attention: There is a plastic cover on the U-shape iron part, must keep the cover on the front side.)




9.Push bar assembly (optional)


Turn the push bar to a proper position, align it with the hole on car body, insert it until attaching the safety mark and fix with the quick release part.




10. Adult's step assembly (Optional)
a: Install the iron part and step with 4*12 flat head screws.




b: Assemble two plastic axle support parts.



c: Inset the axle, install the bushing, washer, wheel and washer in sequence, fix them with cotter pin. Assemble the wheel cover.



d: Attach the assembled adult's step with car body, d fix with the screw and nut.



FUSE

This car has an auto-reset fuse, if the car stops suddenly during driving, it is mainly caused by instantaneous current exceeds ,which makes the fuse to trip. Then just stop operating for about 8 seconds, this fuse can be reset. Then turn on the power switch again. In order to avoid the fuse tripping and cutting off power supply, please pay attention to the following matters.

This product can't be overloaded, the weight limit of the car is 30kg, the weight limit of the car with adult's step is 80kg.

Don't drag anything behind the product.

Don't let the water or other liquid into the batteries and other electrical components.

Don't change the circuit system and structure of the product.

SECURITY WARNING

- 1.The installation and charging of vehicle should be under adult supervision at all times.
- 2.This product is limited to the children from 37 to 95 months, the weight limit of the car is 30kg, the weight limit of the car with adult's step is 80kg, please do not overload.
- 3.This product is ideal for driving on a hard flat surface.
- 4.It is strictly prohibited in the streets or the road, pot holes, and slopes.
- 5.Avoid driving in the sand or grass or uneven ground.
- 6.Children should be given full instructions on operation of the car. Improper operation can cause damage or accidents.
- 7.While children are driving, it is parents' duty to supervise at all time to avoid accidents.
- 8.Avoid driving in rains or flooded pathways. By doing so it can damage the motor, circuit and other electrical equipments.
- 9.Battery charger should be regularly inspected by parents to insure that the wires, plugs, crusts and other components are not damaged. Please stop using if any damage is found, until it is completely restored.
- 10.In order to ensure product life and safety, avoid damage to the charger, battery or electric circuit, the car must use the default configuration of a dedicated charger and power supply.
time is two years.

11.Rechargeable batteries should be removed from the toy before charging.

12..If a quite long time does not use, please cut off the product power, and keep all the switch on "stop" or "off" position.

13.The charger provided is not a toy. It is to be kept away from children.

14.Strictly prohibit using the non-manufacturer provided parts.

15.This product is made of PP material mainly, and the safe using time is two years.

USAGE DIRECTION

1. Before using , make sure that all the following works are done.

- Step described in accordance with the instructions to complete the installation of the car, the battery plug-in has been connected, the power supply has been switched on.

- Make sure that all the positions which need the screws are fixed tightly.

- Parents or guardian should ensure that children have taken the safety measures before using.

To reduce the risk during using, pay attention the followings:

When driving the car ,child should sit on the car seat.

Adult or parents should take more care and guidance when child driving and can't leave away.


Pay attention to the driving environment and driving on the hard flat surface, not the unsafe environment.

For example:


- a.The trenches, the riverside, slope or uneven ground;
- b.Road or other places for driving and walking;
- c.The obstruction which is easily hitting and causing injury;
- d.Other unsafe zones.

To avoid accident, please use only in daytime or bright place, avoid using under low visibility.

2. Operating(function reference diagram)



MP3 Optional



WARNING:

This toy contains batteries that are non-replaceable.
Instructions to be given to the child in the proper use of the toy particularly in the use of any braking system.
A reminder that the toy should be used with caution since skill is required to avoid falls or collisions causing injury to the user or third parties.

MP3 Optional

MP3/ Mode/ Electric capacity display

Wireless name

B: Wireless streaming

T: Big memory

U: Small memory


⚙️: Flash

Volume +

Volume -

Mode

Previous



MP3 balance waveform

Power capacity

Wireless streaming

Music


Story

Next

↑
Microphone input
/ Audio input


↑ ↑
Big memory Small memory

MP4 Optional



Remote control instruction

2.4G Remoter Control Instructions



For the first time using, please match the remote control with the car, this product has a memory function, battery replacement does not need to match the code once again.

- ①. Long press "code" button more than three seconds, until the first LED lights flashing.
- ②. Turn on the power on the car, the first LED light on the remote control turns on indicating the successful pairing with the car.
- ③. When the remote control is not used for a while, it will automatically enter a sleep mode, press any key to wake it up.
- ④. Key Description: "△" Forward, "▽" Reverse, "◁" Left, "▷" Right, "S" Speed, "P" Stop.

Press the "S" key to select the speed, 1 LED indicates low speed, 2 LED indicates medium speed, 3 LED indicates high speed, the car reverse with only medium speed.


Press the "P" key, the car will stop immediately, all LED starts flashing, press this button again to release the brake function.

WARNING:

1. When operating the car, the distance between the car which kid sit in and the remote control which operated by adults should not be more than 10 meters.
2. The remote is only for adults to use, keep far away from child.
3. Before using the remote, please read the instruction manual carefully, and operate the empty car first, only when knowing the way of operation, you can use the remote with kid in the car.
4. This product should not be used on traffic road and the place with water and obstacles.
5. To Avoid damaging the circuit, please keep the remote control from wet and in rains.
6. Don't mix old and new batteries and different brands of dry batteries.

7. In order to avoid damaging the remote control, please take out the batteries if not use the remote control for a long time to avoid battery leakage and circuit corrosion.
8. Avoid dropping the remote control during using.
9. Install batteries with right polarity to avoid battery short circuit.
10. Charging must be done by adults. Non rechargeable batteries can't be charged.
11. Exhausted battery should be removed from the toy properly and prevent children from playing.
12. Take out the battery if no use for long time, properly handle the battery, and prevent children from playing.
13. If the remote distance is less than 3 meters, the battery in the remote control maybe has run out of power , please change 2 pieces of AAA alkaline batteries.


How to insert batteries: Use screwdriver to loosen the screw on the back of the remote control, open the battery cover, and install two AAA 1.5V alkaline type batteries according to the diagram (Batteries are self-provided), then close the battery cover, and fix with screw.



CHARGING WAY

- For Safety purpose ,the charging must be done by adults.
- Before first use, please open the engine cover, insert the fuse to connect the power, use it only after charging 8-12 hours.
- Charging socket is locate on the dashboard, please follow the instructions to charge the battery.
- If the car has slowed down, it needs to be charged by 8-12 hours, maximum 20 hours.

- 1.First insert the plug of the charger into the charging port. (The car can not be used.)
- 2.Then insert the charger to the power socket.



Attention:

- Can only use the charger and battery according to manufacturers regulations.
- Do not mix old and new or different types of batteries.
- The battery terminal should not be short circuit.
- Do not open the battery or charger.
- Do not reverse the battery.
- Before charging, please check whether the charger, battery and plug are no problem, if you find any broken parts, please stop using immediately. And do not use it until it is repaired.
- The battery will be little warm when being charged, it is normal. If not, it may be caused from the short circuit of charger or circuit board.
- Must use the pressing plate to fix the battery.
- Run out of battery must be handled by adults, remove the battery which has run out from toys to recycle properly and shall not be arbitrarily discard.
- If the product is going to be stored unused long time , it must be fully charged, and charge it every month to guarantee the battery life.
- Charger and Battery are not toys. Keep them away from children.

MAINTENANCE AND SERVICE

1. Before using, parents should check whether all parts are in good condition, for example the batteries, charger, wires, plug, outer body and other parts, check whether the screws are loose and whether there are potential safety hazards. Any damaged parts founded should be repaired before using.
2. After using the product for a period of time, use a little amount of lubricating oil for the moving parts to prevent wear and tear of rust.
3. Keep the car away from fire and direct sunlight. Place it stably, not upside down. The car shall be stored indoors or outdoors under cover.
4. The car should be kept away from hot items, such as stoves and heaters, otherwise the plastic parts will melt. When charging, the car should be kept away from inflammable materials to prevent it from catching fire.
5. Charge in time after using. Charging should be done by adults. If the product is going to be unused for a long time, it must be fully charged. Charge it every month to extend the battery lifespan.

6. A soft cloth must be used to clean the car. Do not use chemical solvents to clean the plastic parts. Do not use soap or water to clean the car. Driving in rainy , snowy day or driving in water can damage the motor, battery and circuit system.
7. When stopping or storing the car, please cut off the power and make sure all switches are in the 'STOP' or 'OFF' position.
8. Do not use fuses different from the specifications of this product.
9. Do not change the product structure and circuit system. Maintenance and repair work must be done under the guidance of the professional or technical personnels.
10. Do not use the product for other purposes. Put the battery in the right polarity.
11. Battery negative short circuit is prohibited. Non-rechargeable batteries cannot be charged.
12. Rechargeable batteries can only be charged under the supervision of the adult.
13. Do not mix old and new batteries or different types of batteries.
14. The battery running out of power should be removed from the car properly and not allowed to be played by children.
15. Disconnect the batteries completely when not in use and do not allow children to play with them.

TROUBLESHOOTING

Car does not move or power on	If "power" switch is on "OFF" position
	If the fuse is not functioning properly
	If the battery is not connected, check the red and black wires.
	If the charger is plugged in, car will not be operated. Unplug charger.
	If the pedal switch is not functioning properly
	If the wheels stuck and cannot move
Car moves slowly	If the battery is not fully charged. Need to be charged in time
	If there is an issue with the wheels
	If rider weight exceeds specifications
Battery can not be charged	If the charger is malfunctioning
	If the battery lost its capacity
	If the connection of charger and battery is loose

PINGHU SHUANGXI BABY CARRIER MANUFACTURE CO.,LTD.
PINGHU BABY CARRIER INDUSTRY CITY, ZHEJIANG, CHINA