

Electric Motorcycle Guide Book



**Manual book only for your reference ,
products features may vary from the pictures in book ,
configuration based on your order!
Please read the guide book carefully before using**

Specification :

Item Name	specification
Storage battery	6V4AH
Motor	RS380-6VDC RPM13000
Suitable age	37-95months
Max weight	20KG
Size	82X48X56 CM
speed	1-3KM/H
Service time	Charging 8-12 hours, using 1-2 hours
charge	Input: 100V-240V Output : 6V500mA

- ⚠ Please read the instruction booklet carefully before using. It will illustrate the right fixing procedure and operation for you, just in case any hurt to your kid out of wrong fixing. Besides, this booklet should be kept well for possible reference in future .
- ⚠ Be sure to charge the storage battery full of 18 hours before first-time driving, otherwise it would cause perpetual damage to the storage battery and there will be little possibility to restore.
- ⚠ Do not using up the electric quantity every time.



Functional Indicators:



Functional Indicators:

- (1) Charging Hole
- (2) Music switch
- (3) Speaker switch
- (4) Forward and Backward switch
- (5) light switch

Battery Safety Warning

1. Do not change the structure and circuit system of this product without authorization.
Maintenance work must be carried out by professionals or under the guidance of technicians.
2. Do not use toys for other purposes.
3. Batteries are put in at the correct polarity.
4. Short circuit of positive and negative poles of batteries is strictly prohibited.
5. Non-rechargeable batteries cannot be recharged.
6. Charging batteries can only be charged under adult supervision.
7. Exhausted batteries should be removed from toys and handled properly to prevent children from playing.
8. when you don't use toys for a long time, you should remove batteries from toys and handle them properly to prevent children from playing.

1, Foot plate and support wheel assembly

Align the plate with the body mount, and the support wheel is aligned with the screw hole at the bottom of the body, and then fixed with screws.



2, handle pipe assembly

Firstly, the fender is inserted into the front fork assembly. Two wheel covers are installed on both sides of the wheel. The front axle passes through the front fork hole. The decorative parts are installed on both sides of the front axle, fixed by nuts, and the cap is fixed on the clamp on the decorative parts.



3,Front fork and headlight assembly

The headlight line is connected with the body wiring through the front fork. The front fork is clamped into the body part and the big screw is used to pass through the hole position. Then fixed under the nut. The headlight is fixed to the front fork with the screw.



4,Handle pipe assembly.

Plug the pipe into the front fork, add the mounting fixed with screw



5,Mirror assembly

Note the left and right, fixed with screw.



6,Connect the power cord

Connect the red battery wiring, start the switch to check whether the line is connected correctly.



warning

For your baby's safe driving, you must pay attention to the following warning:

1. assembly and adjustment of products must be carried out by adults. Keep children away from active parts.
2. Containing small parts, it is not suitable for children under 36 months!
3. Children must use seat belts correctly when riding. Do not approach fire!
4. Children must use this product under the guidance of adults, and caregivers must not leave during use!
5. Do not let children stand or play on the pedal (or in the electric car).
6. Battery charging must be done by adults. Please charge before using this product!
7. In order to avoid harm to children, please keep plastic bags and other packaging materials away from children! Suffocation danger!
8. Do not use any accessories provided by non-manufacturers.
9. Do not use the charger as a toy.
10. The maximum load-bearing weight of this car is 20KG, so it can not be overloaded.
11. The age range of this car: 37-95 months
12. toys can not be connected to more than the recommended number of power supplies.
13. Products may contain sharp edges or sharp edges before assembly, leading to potential hazards!

note

1. It shall not be used in dangerous areas such as public transport roads.
2. No modification of the line of the car and additional live devices.
3. This product is limited to passengers, can not be overloaded, and the maximum load is 20KG.
4. When not in use, please turn off the power switch. When not in use for a long time, please unplug the battery connector.
5. The battery charger should be checked regularly to see if the cable plug housing and other parts are damaged and stop using until repair is complete.

Attention when charging

- 1, When using electric vehicles for the first time, the battery must be charged up to 10 hours, otherwise the battery will be permanently damaged and can not be repaired.
- 2, When charging, the DC plug of the charger is inserted into the charging socket, and then the charger is inserted into the power socket. When the vehicle is charging, the toy (the whole vehicle) is not operable.
- 3, Each use of an hour, it must be charged in time, the normal charging time is 8-10 hours, and each charge time must not exceed 18 hours.
- 4, During the charging process, the heating of the charger and battery is normal (below 60 degrees).
- 5, If there is water in the connector, it can not be charged, otherwise it may cause short circuit.
- 6, The electric vehicle must use the electrical equipment provided by the vehicle in order to avoid damage to chargers and batteries or short circuit.
- 7, When the electric vehicle is not used for a long time, it must be charged at least once a month.

Charging Step

- 1: Charging Hole on Operating Board
- 2: Plug Charger Plug into Plug Hole;
- 3: Plug the charger into the power outlet.



Care and maintenance

1. Before use, parents should check whether the charger's wires, plugs, housing and other parts are damaged, and stop using until repaired.
2. After a period of use, lubricate the iron parts of the vehicle with a small amount of wet Wei oil to prevent wear and rust. The vehicle should be stored away from the fire source and avoid long-term illumination. When stored, it should be flat upward, not upside down or inclined. The car should be parked indoors or covered with waterproof cloth.
3. Vehicles should be away from hot objects, such as stoves or heaters, and plastic parts may melt. When charging, keep away from inflammable materials to prevent fire.
4. After use, please charge in time, charging must be adult operation. If it is collected or not for a long time, it must be filled with electricity and then recharged once a month to extend battery life.
5. Dry soft cloth can be used to wipe vehicles, and non-waxy furniture polishing material can be used instead of soft cloth to wipe parts of expected material, which has achieved the effect of surface polishing. Do not use chemical solvents to wipe the plastic parts of toys, do not clean vehicles, do not drive outdoors in rainy or snowy weather, water will damage the motor, circuit system and battery of vehicles
6. when stopping using or placing products, please cut off the power supply of products, all switches to the "stop" or "off" position.
7. do not use protectors that do not conform to the specifications of this product.
8. Do not change the product structure and routing system without authorization. Maintenance must be carried out by professionals or under the guidance of professionals.