Safe use of rules

Must by adults on the local assembly, please check whether the device and circuit assembly assembly process correctly.
Default of banned in the streets, highways, landslides and other dangerous places.
Children must be under the custody of adult use.
When used on the local, please do not casually change device.
When use, shall not be frequently switch forward backward function.
Please check the battery, line, plugs, and other parts for damage and found damaged, please stop using in time,
Until the restored can be reused.
"non-rechargeable batteries are not to be recharged"
Should be in the right electrode in the battery.
Run out of battery should be removed from the toy.
The power terminals shall not be short

Charging matters needing attention

1, using electric vehicles for the first time to charge first! Charging in car tail, charging charging Cover first then put the plug in the charging socket, then the charger plugged in. (charging must Be made into do, do not let your children's access to power supply)
2, please recharge immediately when electric vehicle driving speed slowed significantly, continuous Charging 8 to 10 hours, not more than 10 small at the right time.
3, in the process of charging the charger or battery have fever phenomenon (under 60 ℃) are Normal.
4, the electric car must use local car equipped with dedicated charger and battery, so as not to Damage the charger and battery and electric circuit.
5, the electric vehicle charging shall not do any operation.
6, please a mixture of old and new or different types of batteries.
7, electric vehicle charging, please check whether the circuit connection is correct.
8, when the electric conductor time when not in use, must charge at least once every month.

Warning: electric car used in non private places, may lead to drowning, burns, falls and other hazards.

ELECTRIC CAR

Install and use the manual

Manual has an important information, read, please keep for future reference.

Mercedes-Benz

STANDARDS:EN71、EN62115

TROUBLESHOOTING

PROBLEM	ANALYZE	SOLUATION
Car doesn't work	• Low power	Recharge the battery
	• Damage of thermic fuse	Change with new thermic fuse
	• Lose of wheel nut	Use new nut
	• Loose of battery connector	Put on the connector
	• Exhaust & bad battery	Change with new battery
	• Damage on electrical parts	Go tarepair shop
	• Damage on motor	Go to repair shop
Battery can't be recharged	• Loose of the battery connector	Tighten the connector
	• Charger doesn't plug the power	Plug charger with power
	• Damage of charger	Change new charger
Short of run time	• Battery with lower power	Recharge the battery fully
	• Battery is old	Change new battery
Noise & Heat during recharge	• It's chemical process	It's normal & safety
Low Speed	• Old battery	Use new battery
	• Low power	Recharge the battery fully
	• Over burden	Reduce burden under 25KG
	• Run on not-flat ground	Run on flat ground
Noise of gear box	• Damage of gear box	Go to repair shop
	• Damage on motor	Go to repair shop
Car shake when running	• Bad connect of motor wire	Reconnect the wire
	• Motor doesn't work well	Go to repair shop
No sound & light when running	• Loose of sound & light wire	Connect the wire
	• Damage of sound & light board	Go to repair shop
Car can't stop in run	• Damage of electrical parts	Go to repair shop
Unusal working condition under Remote control	• Remote control battery exhaust	Change battery
	• Remote control out of distance	Keep near distance between car and remote control
	• Damage of remote control	Damage of remote control
	• Damage of receiver board	Change receiver board
	• Disturb of magnetic filled	Far away from magnetic filed

Install know that

Install windscreen

First remove the windscreen, then align the windscreen frame to the vehicle body, and press firmly to hear the kachashing installation in place.
(as shown in figure 7)

Functional instructions
1 first open the key to the total power supply, the lights lit up and accompanied by the start of the sound.2 move the steering wheel button, this time the music rings. Sound size adjustment will be up and down the first switch key press, can be achieved.3 the upper left corner of the music board is MP3 interface, the following is the memory card insertion port and next to the USB jack.4 point move "story /V+" key, this time for the story mode.5 "music /V-" button, at this time for the song mode.6 point move "ancient poetry / play" key, this time for the ancient poetry mode.7 "early" button, at this time for early education mode.8 point "horn" key, this time for the speaker mode.9 "forward and backward" switch forward gear, step on the pedal switch car forward. Will "go back" after the switch back, step on the foot switch the car to run backwards. 11 the red circular switch is the swing start button, and the switch can realize the swing function.
(as shown in Figure 8)

CHARGE METHOD

1.First it is the please open the cushion , and the battery connections with mum distributing frame, with red is red and black is black, not a line ends meet, or cause a short-circuit.
2.Charging socket the cushion down side, and nocks rechanging, charger plug in the outlet, then insert the power outlet.
3.The train slowly, in charge, the time for 8-10 hours, and not more than ten hours.
4.In the first to use the deposit, we must ensure that the cell battery up to 10 hours, otherwise, permanent damage cells and beyond repair.
5.Charging devices or battery which has a trace (60 ℃) are normal.
6.The electric baby must use car is equipped with the charger and the battery, in the case of broken the cell phone chargers and the counter-voltage or an electric circuit.
7.Have to recharge the batteries to be recharged from the top the use of battery.
8.Not mixed with the old and new or different types of batteries.
9.Can't insert the battery wire connector.
10.When the baby is not for a long time, at least once every month to charge.
11.Toys can't connect to the surplus on the use of the recommended amount.
12.When the car is charging,can't use it.

PACKING LIST

✱ Car body (popPropylene)	1PC	✱ Charger	1PC
✱ The steering wheel	1PC	✱ MP3 connector	1PC
✱ Chair	1PC	✱ Manual	1PC
✱ Car wheel, bocks	4PCS	✱ Remote controller	1PC

UNIT MOUNT

Installation mirror

First, differentiate the left and right Mirror, and then rewind.
Insert the left and right of the door.
(as shown in figure 4)

Charging instructions

Before installing seat first connect the positive, and then put seat in the specified location, card hook body card slot, then put the front seat fixed on both sides of the hole with the screw clockwise tightened when charging, open cover charge first, and then insert the charger to charge hole, when charging the vehicle without any function, (as shown in figure 5)

Remote control battery installation

First use the screwdriver to unscrew the screw on the battery cover, then take out the battery cover and remote control into two A ^A1.5 V batteries, and battery cover cover and screw locking. (see figure 6)

Install the front wheel

On the gasket, the lining of the shock absorber into the front axle, then the front wheel set into the front axle, and then set into the gasket and the locknut, with nut wrench should be fixed, cover the cap, About the same installation
(as shown in figure 1)

Install the rear wheel

Will first car body over, remove manual damping spring and bushing inside, and then put a spring in car suspension hole, then set into the sleeve, and then use 10 mm rear axle through the sleeve and body, in turn will spring is fixed inside the car. Then through the rear axle, gear box positioning on the car, and then the connectors on the gear box connected to car connector, then insert the wheel shaft, set into the big gasket, then its fixed with a locknut, finally cover the wheel cover.
(as shown in figure 2)

Install the steering wheel

Will line connectors and direction in the direction of dish stem line connectors are connected (note that connect the positive and negative), Then put the steering wheel in the direction of the pole, with the M5 inner hexangular set screw rod through the steering wheel and direction in turn. (as shown in figure 3)

USE CAUTIONS

1.In the first to use the deposit, we must ensure that the cell battery up to 10 hours, otherwise, permanent damage cells and beyond repair.
2.In the streets, roads, slope, ditch and the danger area.
3.Please don't on the polished surface, such as marble,tile on the surface.
4.This product by one, not limit, the greatest relief is over 30KG.
5.Don't run in an electric switch on deposit in the back of the light switch.
6.Shall not be altered the car circuit or device to additional changed made in wear and keep away from sources of ignition to avoid causing the damage.
7.The remote control and not to let it get caught in the rain or otherwise 1)Manual used in illustrations to explain the product of the operations and products, with the installation of structure in the existence of a small difference in kind, please standard the object.
2)In order to improve product quality, not to notice, we may change the part of the structure and appearance, please forgive.
3)This package contains important information that must be to keep.
4)Cannot be used in rainy days.
5)Can not use water to clean.
6) Assembly by an adult."
7)•Warning:Protective equipment should be worn.Not to be used in traffic."
8)Toy operation requires a certain technology, should be more careful when used, lest collision and fall lead to injury and injury to others.
9. Batteries are to be inserted with the correct polarity.
10. Exhausted batteries are to be removed from the toy.
11. The supply terminals are not to be short-circuited.
12. Products should be properly assembled by the adults and then use.
13. Please do not use in the streets,roads,landslides and other dangerous places,must be used under adult guardianship.

Use the product please first read instructions,it will tell you the correct methods of operation and installation instructions.To avoid not correct methods of operation of this product or injury and damage or injury and your baby.
Manual should be placed to take good care of.
It's STANDARD NO.:EN71 EN62115 ASTM F963

DECLARATION:

1)Manual used in illustrations to explain the product of the operations and products, with the installation of structure in the existence of a small difference in kind, please standard the object.
2)In order to improve product quality, not to notice, we may change the part of the structure and appearance, please forgive.
3)This package contains important information that must be to keep.
4)Cannot be used in rainy days.
5)Can not use water to clean.
6) Assembly by an adult."
7)•Warning:Protective equipment should be worn.Not to be used in traffic."

SPECIFICATION

Battery	12V4.5AH
Motor	12V20W 12V15W
Charger	Input:AC220V~240V、50HZ~60HZ,Output:DC12V1A
Maximum load	30 KG
Work Time	Recharge 8-12h,Use for 1 h
Speed	3-5 KM/H
Age	37 months - 96 months
R/C Battery	AAA 1.5V * 2
R/C Distance	15±5M

SAFE RULES

Non-transportation, must be care of adult!

Warrnning △ Before using the child for education, safety!

1.Be charged by an adult, don't let the children touch.
2.Driving, we must by adults, and the mileage use.
3.Clamp down on the streets, roads, slope, waiting for over a backward, to eliminate obstacles to ride.
4.It's suitable for children for about 37-96 months.
5.Cycle shall not leave the seat to prevent operation resulting in injury.
6.In the car was pulled, the device, such as a block, please immediately release switch to eliminate the obstacles and foot before you ride.

1.Non rechargeable battery can not be charged
2.Power supply terminals shall not be short connected
3.Rechargeable batteries can only be charged under adult guardianship
4.Different types of batteries or do not mix old and new batteries
5.The battery should be put in the correct electrode
6.The exhausted battery should be removed from the toy
7.The charging battery should be taken out from the toy
8.Contains small parts,not suitable for children under the age of 3 to use
9.Products should be properly assembled by the adults and then use
10.Please do not use in the streets roads landslides and other dangerous places must be used under adult guardianship
Cannot be used in rainy days.
Can not use water to clean.
Assembly by an adult."
Protective equipment should be worn. Not to be used in traffic."
Warnnng:This toy is unsuitable for children under 3 years due to its maximum speed

Using The Matters Needing Attention

Products should be assembled by adult right further use.
Battery charging should be carried out by adults, must first be charged before using this product.
The first use of electric vehicles, must ensure that the battery full 10 hours! Otherwise it would be permanent damage
Pool and beyond repair.
Please don't in the street, the road, landslides and other dangerous places, and be sure to use under adult supervision.
This product is limited to a person, do not overload, the largest capacity of 30 kg.
Please fasten your seat belt, and make sure that your baby is always sat on the bench, at the same time, please do not let the baby in
Routine stand or do some dangerous action.
Please don't suddenly change in the process of electric vehicles run forward/backward switch.
To prevent collisions with valuables, please do not use in a relatively narrow space, in order to avoid damage to electric vehicles.
Please check for product and the charger, check the wires, plugs, self packaging and other components
Damaged, found that the damage should stop music to be repaired before use.
When not in use for a long time, please turn the power off and remove the battery connector.
Children must use under adult supervision.
Suit age period: three years.
Please do not use in the streets, roads, landslides and other dangerous places, and must be used under adult guardianship.
The toy should be used with caution since skill is required to avoid falls or collisions causing injury to the user or third parties.